



Designed for rugged industrial applications, the AFK floor scale delivers reliable performance and an extra-large pan for weighing items up to 600kg. Its sleek, stainless steel indicator boasts superior sealing to protect from dust and ensure longevity. The oversized, backlit display is clearly visible, and the large buttons make the keypad easy to see and use in any environment. The AFK is an excellent choice for parts counting, percentage weighing and dynamic weighing, while built-in limit lights make it ideal for checkweighing. Date and time are supplied by the indicator and included in printouts.

## Extra-large pan for weighing oversized items or counting large quantities



### Features

- Vivid, backlit LCD easily visible in any lighting conditions
- Capacity tracker built into display for easily monitoring possible overloads
- Programmable backlight can be set to "always on," "always off" or "light only when weighing"
- Checkweighing LEDs clearly show under, over and acceptable limits
- Colour-coded keys facilitate quick recognition of the most frequently used buttons
- Heavy-duty rubber feet ensure stability of unit
- Large, grade 304 stainless steel pan allows easy cleaning
- RS-232 interface is available to provide speedy connection to computers and printers
- Rugged construction stands up to industrial use
- Sealed keypad protects against dirt and spills
- Wall-mount bracket for placing indicator on vertical surface
- Checkweighing with audible alarm
- Parts counting with preset sample sizes
- Simple operation allows quick startup and use with little or no training
- Zero-tracking feature ensures display returns to zero reading
- AC adapter included
- Rechargeable battery included for operation almost anywhere
- Programmable auto power-off to save energy

### Applications

- Weighing
- Parts counting
- Percentage weighing
- Checkweighing
- Dynamic / animal weighing

### About ADAM:

For more than 40 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Model	AFK 75	AFK 150	AFK 300	AFK 600
<b>Capacity</b>	75kg	150kg	300kg	600kg
<b>Readability</b>	5g	10g	20g	50g
<b>Repeatability (S.D.)</b>	5g	10g	20g	50g
<b>Linearity (+/-)</b>	10g	20g	40g	100g
<b>Pan Size</b>	400x500mm			600x800mm
<b>Weighing Units</b>	kg, lb, lb:oz, oz, N			
<b>Stabilisation Time (sec)</b>	2			
<b>Interface</b>	RS-232			
<b>Calibration</b>	External calibration			
<b>Display</b>	Backlit LCD with 40mm -high digits			
<b>Power Supply</b>	12VDC 50/60Hz 800mA adapter / Internal rechargeable battery			
<b>Operating Temperature</b>	-10° to 40°C			
<b>Housing</b>	Stainless steel indicator with die-cast aluminum base			
<b>Overall Dim.</b>	400x620x790mm (wxdxh)			600x940x830mm (wxdxh)
<b>Net Weight</b>	12.8kg			24.3kg

## Accessories

Item number	Description
3102311619	In-use cover
1120011156	ATP thermal printer
3126011263	ATP thermal printer paper
3126011281	ATP thermal printer paper (pack of 10)
700400103	RS-232 cable
3074010507	RS-232 to USB adapter (must order corresponding RS-232 cable)
1100011297	AE402 relay box
600002028	Adam DU data collection program
700660288	Calibration certificate (AFK 600)
700660290	Calibration certificate

## Key Accessories



**ATP thermal printer**  
Easy-to-use features combined with quick set-up equals a truly versatile thermal printer. A single push-button feed key and three easy-to-read LED indicators make operation simple.



**Relay Box**  
The relay box is connected by wire to the scale, and helps transmit signals to other devices.



**In-use wet cover**  
In-use covers provide an easy and affordable way to help keep the balance clean and protected.

Supplied by